



## Operating Instructions



**Shirt Finisher  
VEIT 8325**

**Table of Contents:**

<b>1</b>	<b>General Information</b>	<b>3</b>
1.1	Introduction	3
1.2	Warnings and Safety Instructions	4
<b>2</b>	<b>Installation Instructions</b>	<b>5</b>
2.1	Drawing and Dimensions	5
2.2	Installation	6
2.3	Assembly of the Form	6
2.4	Assembly of the Sleeve Tensioners	6
2.5	Assembly of the Control Panel	6
2.6	Electrical Connection	6
2.7	Steam Connection	6
2.8	Compressed Air Connection	7
<b>3</b>	<b>Operating</b>	<b>8</b>
3.1	Commissioning and Start-up	8
3.2	Description of Control Elements Controls	9
3.2.1	Control Panel	9
3.2.2	Pedal Switch	12
3.2.3	Pressure Controllers	13
3.3	Operation Procedure	14
3.4	Menu Structure	15
3.5	Configuration of the machine	18
<b>4</b>	<b>Maintenance and Service</b>	<b>19</b>
<b>5</b>	<b>Malfunction and Troubleshooting</b>	<b>20</b>
5.1	General	20
5.2	Error Messages on the Display	21
<b>6</b>	<b>Technical Data</b>	<b>22</b>
<b>7</b>	<b>Circuit Diagrams</b>	<b>23</b>
7.1	Pneumatic Plan	23
7.2	Electrical Circuit Diagram	25
<b>8</b>	<b>Position of Throttles</b>	<b>32</b>
<b>9</b>	<b>Types of Valves</b>	<b>33</b>
<b>10</b>	<b>Spare Parts</b>	<b>34</b>
<b>11</b>	<b>Information Leaflet</b>	<b>42</b>
<b>12</b>	<b>EC Declaration of Conformity</b>	<b>47</b>

# **1 General Information**

## **1.1 Introduction**

The Shirt Finisher VEIT 8325 enables an excellent and complete finish for all kinds of shirts either washed, pre-treated or humidly treated garments. Before being finished the shirts are put on hangers and are finished either buttoned or open. The seam tensioning elements, made-to-measure shoulder forms, electrically heated lapel plates for the front shirt pocket and the integrated suction clamp are all standard features. After being finished the garments can be unloaded automatically (option) and be transported to the folding tables or packaging department by a transport system.

## 1.2 Warnings and Safety Instructions

- Only use the voltage and type of current shown on the machine plate.
- The unit is supplied with a plug. Do not connect without a plug. The plug must be easily accessible and must not be covered by any components.
- The main electrical supply is the responsibility of the customer. Take note of the regulations of the local electric suppliers.
- Electrical faults must only be repaired by authorized personnel.
- Disconnect the power, air and steam supply before opening the machine.
- In case of emergency the machine can be stopped by pulling out the main plug by operating the main switch or by operating the STOP button on the control panel.
- Don't put your hand into the guides of the seam tensioning elements and into the mechanics of the front sleeve tensioners. - Danger! You may trap your hand!
- Don't reach into the area between the button clamp and the form! Danger of burning!
- Steam and condensate lines must have a stop valve.

Hot steam can burn you; take care!

Therefore: You must take special care when testing the steam without using a garment!  
Keep a safe distance!




1. Don't reach into the area below the form!
2. Don't touch steam and condensate lines!

Use only VEIT accessories and Spare Parts.

## 2 Installation Instructions

### 2.1 Drawing and Dimensions



## 2.2 Installation

The unit should be installed on a level floor. Any unevenness of the floor can be overcome by adjusting the rubber feet.

## 2.3 Assembly of the Form

The form is fixed with four cylinder screws on the form console.



## 2.4 Assembly of the Sleeve Tensioners

The exact adjustment of the height has to be done with a long sleeved shirt when starting the operation. The correct position is when an optimum tensioning is reached at the position long or short sleeve.

## 2.5 Assembly of the Control Panel

Open screw (1) and (2) , then take away the transport safety device (3) and move down control panel on machine level.

Fix on basic frame with screw (1).



## 2.6 Electrical Connection

The unit is already fitted with a Ceecon-plug (400 V) for connection when it is supplied.



**Attention: Do not connect without plug.**

Install the connection cable so that it will not touch hot steam lines.

## 2.7 Steam Connection

Have your steam lines connected in accordance with technical principles and regulations. Steam and condensate lines must have a stop valve.

## 2.8 Compressed Air Connection

Take the maintenance unit out of the packing and screw it to the fastening angle provided at the back of the machine.

Screw the swivelling screw fitting with the eye bolt in the maintenance unit.

Push the compressed air hose over the hose nozzle on the maintenance unit and fasten it with a hose clamp.

Install the compressed air hose so that it will not touch hot steam lines.

The pressure adjustment of the maintenance unit has to be 5.5-6.0 bar.

### Attention



**When the machine is connected to the compressed air supply, the seam tensioning elements, sleeve tensioners and lapel clamps return to their home position. This also happens when the unit is switched off.**

## 3 Operating

### 3.1 Commissioning and Start-up

Open condensate return line and steam supply.

Open the compressed air line.

Switch on the main switch on the left side of the machine.

The display on the control panel shows the pre-adjusted values.

All flexible parts of the machine move to their starting position.



**Caution:** The sleeve tensioners move quickly when opening the compressed air line.

The unit is ready for operation after heating up for approx. 15 minutes.

Carry out some steaming tests without a garment to test the steam quality before operating the machine.



**Attention:** Danger of burning by hot steam. Keep a safe distance!




## 3.2 Description of Control Elements Controls

### 3.2.1 Control Panel

The control panel is equipped with all elements necessary to operate the unit.

The red light emitting diode (called LED) on the optional keys signalize if the respective option is switched on.



#### 1. Rotary button **Steam time**



To set the steam time between 0-30 seconds. The adjusted time is shown on the display above the rotary button.

#### 2. Rotary button **Steam-Air Time**




To adjust the steam-air mixture between 0-30 seconds. The adjusted time is shown on the display above the rotary button.

**3. Rotary button Air Time**


To adjust the air time between 0-180 seconds. The adjusted time is shown on the display above the rotary button.

**4. Rotary button Air Quantity (Option)**


To adjust in steps the air quantity to dry the garments. The adjusted quantity is indicated on the display above the rotary button.

**5. Press key Suction Button Tape**


To activate the suction of the button tape.

If this option is activated (LED on) the button tape will be suctioned first, then the button pressure clamp is pressed down manually and the lower end of the button tape is being pressed down automatically by the button tape tensioner.

If this option is deactivated (LED off), the button pressure clamp is pressed down manually first, the button tape will not be suctioned.

When LED flashes, suction, the button pressure clamp and the breast pocket are deactivated. The first step is determined by other optional keys.

**6. Press key Back Pleat (Option)**


If this option is activated (LED on), the back pleat is pressed.

**7. Press key Back Clamp**


If this option is activated (LED on), the back clamp is switched together with the last side clamp.

**8. Press key Retensioning Side Back**


If this option is activated (LED on), the sides and the back of the shirt are retensioned during the steam phases. For pressure adjustment refer to 3.2.3.

**9. Press key Pieces Counter**


To set the pieces counter on the right side of the display to zero the key is pressed longer than 3 seconds.

**10. Press key Plus**


To activate the **next** programme.

**11. Press key Minus**


To activate the **previous** programme.

**12. Press key Menu**


To get into another menu.

If there is no input after 10 seconds the menu returns to the last position.

**13. Press key Stop**


To move the machine back to the neutral position from any operating position.



**Attention: All flexible parts move back to their starting position!**

**14. Press key Step back**


To go back to the last control step.

**15. Press key Short Arm**


If this option is activated (LED on), the side tensioners are under permanent pressure. The shirt is continuously tensioned during the finishing cycle.

If the option short arm is activated, the option long arm is automatically deactivated.



### 16. Press key **Long Arm**

To move the sleeve tensioners to the long-arm position. The LED has to show long-arm position (LED on).

The sleeves are now tensioned by the pneumatic sleeve clamps for one second.

If the option long arm is activated, the option short arm is automatically deactivated.

If none of both sleeve tensioning options is activated (LED off), the sleeve tensioners move totally outwards to inoperative position. The sleeves are not tensioned.

To activate the tensioning function again, one of both keys has just to be pressed and the sleeve tensioners are adjusted to the selected operation mode.



### 17. Press key **Side Clamp**

If this option is activated (LED on), the side clamps are activated after side tensioning.

With flashing LED the side clamps are activated in sequence during the tensioning process, i.e. first the right and then the left side clamp moves in. Then the side tensioners move out.



### 18. Press key **Breast Pocket**

If this option is activated (LED on), the breast pocket is pressed during the finishing cycle.

If the LED is flashing, a finishing cycle is activated. The breast pocket is pressed after 1 –2 seconds time-lag, then it is pressed down again for 2 seconds, now the breast pocket remains in neutral position for approx. 2 seconds before being pressed again until the end of the finishing cycle.

## 3.2.2 Pedal Switch


The right pedal switch activates the tensioning elements step by step.

The left pedal switch sets the tensioning elements back step by step.

### 3.2.3 Pressure Controllers

Five pressure controllers on the left side of the machine make it possible to adjust the pressures for the following functions:

**Attention:** When the option “Anti-Stretch” is activated, the pressure for “side tensioner retensioning” has to be adjusted to 0.



**Attention:** If the pressure is too high it can damage the fabric of the garment to be finished. Please check correct setting before starting!

### 3.3 Operation Procedure

After setting all parameters and requested functions the finishing cycle can be started:

Position the garment and check collar position

Adjust the position of the button tape

1. Activate the right foot pedal – vacuum is activated.  
Button tape of the garment must be adjusted.
2. Activate the right foot pedal – the sleeve clamps move inwards; the button tape tensioner moves out.
3. Manually push the button pressure clamp.

Suction function will be switched off.

4. Position the right sleeve into the right clamping device and then activate the right foot pedal – the right sleeve is being clamped.
5. Position the left sleeve into the left clamping device and then activate the left foot pedal – the left sleeve is being clamped.
6. Both sleeves are being tensioned and the automatic finishing cycle starts.
7. At the end of the finishing procedure the lapel clamps and sleeve tensioners move back to their home position. The garment can be taken off.



**Caution: Do not put your hands into the moving parts and into the mechanics of the lapel clamps and sleeve tensioners!**

If the step back key is pushed during the automatic finishing procedure, the procedure is stopped by the programme, the left sleeve tensioner moves inwards and the tensioning mechanics of the cuff open.

### 3.4 Menu Structure

**User levels:**

- A: not authorized, machine is blocked
- B: authorized to select programmes, not to change any parameters
- C: full authorization for use

- The menu key is blocked during the tensioning and finishing process. The machine is only operable on the operation level.

Menu structure									
	Menu key	Step-back key	Plus key	Minus key	Rotary button "steam time"	Rotary button "steam-air time"	Rotary button "air time"	Rotary button "air quantity"	Autho-ri-za-tion
M 1: „Programme selection“ =user level (for user B and C only)	Step to next higher level, if C, or change to password entry (A, B)	Step back (during tensioning or finishing cycle)	Selection of programme number	Selection of programme number	Input of parameters [0-20sec.]	Input of parameters [0-20sec.]	Input of parameters [0-180 sec.]	Input of parameters [0-100% / 5%]	B, C
M 2: „Entry of password“	Step to user level	Step to user level	Confirm and step to next higher level	Step to user level	Password Pos. 4 (alpha-numbers)	Password Pos. 3	Password Pos. 2	Password Pos. 1	A-C
M 2.1: „Password invalid“	Step to user level	Step to user level	Step to user level	Step to user level					
M 3: „Storing“	Step to next higher level	Step to user level	Confirm and step to user level	Refuse, step to user level				Selection of programme number by over-writing [1-10]	C
M 4: „Change user level“	Step to next higher level	Step to next lower level	Confirm and step to user level	Refuse, step to user level				Select user level [A-C]	C

	Menu key	Step-back key	Plus key	Minus key	Rotary button "steam time"	Rotary button "steam-air time"	Rotary button "air time"	Rotary button "air quantity"	Authoriza-tion
M 5: „Parameters breast pocket“	Step to next higher level	Step to next lower level	Confirm and step to user level	Refuse, step to user level			Period of first pressing [in 1/10 sec., 0...25], default 3,0 sec.	Period of pause [in 1/10 sec., 0...25], default 1,0 sec.	C
M 6: Parameter „unloading“	Step to next higher level	Step to next lower level	Confirm and step to user level	Refuse, step to user level			Period of unloading [in 1/10 sec., 0...25,0 sec], default 5,0 sec.	Period of time-lag until unloading [in 1/10 sec., 0...5,0 sec], default 1,5 sec.	C
M 7:	Step to next higher level	Step to next lower level	Confirm and step to user level	Refuse, step to user level				Time-lag between tensioning and steaming [in 1/10 sec., 0...5,0 sec], default 1,0 sec.	C
M 8: Parameter „antistretch“								Period of moving inwards after side tensioning [in 1/10 sec., 0...2,0 sec], default 0,5 sec.	C



	Menu key	Step-back key	Plus key	Minus key	Rotary button "steam time"	Rotary button "steam-air time"	Rotary button "air time"	Rotary button "air quantity"	Authori-za-tion
M 9: Parameter „antistretch“							Period of moving out, between side tensioning [in 1/10 sec., 0,5...1,5 sec], default 1,0 sec.	Period of pause between side tensioning and untensioning [in 1/10 sec., 0,2...1,5 sec], default 0,3 sec.	C
M 10: Display „Change password“	Step to next higher level	Step to next lower level	Confirm and step to next sublevel	Refuse, step to user level					C
M 10.1: „Enter old password“	Step to next higher level	Step to next lower level	Confirm and step to next sublevel	Break off, step to user level	Password Pos. 4 (alpha-numbers)	Password Pos. 3	Password Pos. 2	Password Pos. 1	
M 10.1.1: „Password invalid“	Break off, step to user level	Step to next lower level	Break off, step to user level	Break off, step to user level					
M 10.2: „Enter new password“	Step to next higher level	Step to next lower level	Confirm and step to user level	Break off, step to user level	Password Pos. 4 (alpha-numbers)	Password Pos. 3	Password Pos. 2	Password Pos. 1	
M 10.3: „Confirm new password“	Step to next higher level	Step to next lower level	Confirm and step to user level (=new password is active)	Break off, step to user level	Password Pos. 4 (alpha-numbers)	Password Pos. 3	Password Pos. 2	Password Pos. 1	
M 10.31: „Password invalid“	Break off, step to user level	Step to next lower level	Step to "enter new password"	Break off, step to user level					
M 11: „Restore preset values“	Step to next higher level	Step to next lower level	Confirm and step to user level	Refuse, step to user level					C

User A: not authorized to make any modifications, password is only requested when pressing the menu key.

The parameters adjusted in the menu are independent from any programme, options, however, are integrated in the programme. The counter is independent from the programme.

„Restore preset values“: All parameters adjusted in the menu are set back to the standard values, the values preset in the configuration menu are not affected.

If there is no new input after approx. 10 seconds, the programme goes back to the user level.

### 3.5 Configuration of the machine

#### Key combinations (Activation during start-up):

1. „**Stop**“+„**Step back**“: Set back password (standard: VEIT)
2. „**Plus**“+„**Minus**“: Primary initialization, configuration of all standard values
3. „**Step back**“+„**Minus**“: Configuration menu

#### Configuration menu:

- to be opened by starting up and pressing the keys “step back” and “minus” at the same time.

	Description	Contents	Value after primary initialization
1. Parameter	Software configuration	1: Standard	1
2. Parameter	Unloader	0: inactive 1: active	1
3. Parameter	Configuration of air quantity adjustable	0: off 1: on	0
4. Parameter	Maximum value air quantity	Configure analog value	210
5. Parameter	Antistretch activated	0: inactive 1: active	0
6. Parameter	Time, move out sleeves, long arms	in 1/10 sec.	1.5 sec.
7. Parameter	Time, move out side tensioners	in 1/10 sec.	1.0 sec.

Use the Plus-key to confirm and store new configurations immediately.  
Use the Stop-key to break off. The actual parameter will not be stored.

## **4 Maintenance and Service**

Pneumatic-maintenance unit: Drain off the water trap periodically and clean the filter element.

Clean the right and left fluff filters regularly.

Clean the impeller every 8 weeks.

Whenever necessary, clean, wash or replace the covers of the form, the lapel clamps and the sleeve clamps, to maintain good finishing and drying.

## 5 Malfunction and Troubleshooting

### 5.1 General

Problem	Cause	Solution
Insufficient suction and blowing effect	Fan works in the wrong direction	1. Switch off unit 2. Pull out main plug <b>Caution!</b> <b>Danger by electric shock!</b> Open unit plug, change phases L1 and L3
Insufficient suction and blowing effect	Cover is dirty or clogged	Replace the cover
Loud fan noise	Dirty impeller and therefore out-of-balance	1. Switch off the unit 2. Pull out main plug Clean the impeller
No indication on the display when switching on	No input voltage Fuses F1/F2/F3 on the mounting plate are defective	Check the unit plug and the main fuse Check the fuse, replace if necessary
The movable components do not react	Input pressure is too low	Set the input pressure at 6 bar
The pedal switch does not operate the machine	Foot switches (S2, S3) are defective or cables are damaged	Check the switches and the cabling (see LED-I/O card)
Anti-Stretch without effect	“Side tensioner retensioning” impressed with pressure	Adjust pressure of “side tensioner retensioning” to 0 bar

## 5.2 Error Messages on the Display

Error 10	Error of internal storage (EPROM)
Error 20	Short circuit of card 1
Error 21	Short circuit of card 2
Error 22	Short circuit of card 3
Error 23 and Error 26	Transmission error of card 1
Error 24 and Error 27	Transmission error of card 2
Error 25 and Error 28	Transmission error of card 3

Errors cause a stop of system, the machine stops, the error has to be corrected by the Stop key.


Once an error is confirmed, it is not indicated any more until the machine is started again.

## 6 Technical Data


Steam connection:	1/2", max. 6 bar
Condensate connection:	1/2"
Compressed air connection:	NW 6; 5.5 - 10 bar
Compressed air consumption:	12 l/min.
Electrical connection:	400 V three-phase current/ neutral wire and earthed conductor separated according to the VDE-regulations
Electrical power:	2.2 kW
Fuse protection:	20 A
Year of construction:	see machine plate
Measurements: Height:	1585 mm (incl. assembled form)
Width:	900 mm (when sleeve tensioners are not moved out)
Depth:	1090 mm
Weight:	290 kg

## 7 Circuit Diagrams

### 7.1 Pneumatic Plan




Optional Ärmelklemmen einstellbar







## 7.2 Electrical Circuit Diagram



Netzseitige Absicherung / fuses of power supply :  
3 x 20A (mit Luftmengenstellung / with changeable air quantity)



Netzseitige Absicherung / fuses of power supply :  
3 x 20A (mit Luftmengenstellung / with changeable air quantity)





Freigabe 15.11.00

Size	Document Number	Rev
A3	8325, Seite 1	WM
Date:	Wednesday, November 15, 2000	Sheet 1 of 7


Version 3x200..240V / 50..60Hz



Version 3x380..415V / 50..60Hz




Knopfdruckleiste mit elektronischem Temperaturregler  
Brusttaschenheizung rechts mit Bimetallregler  
Brusttaschenheizung links mit Bimetallregler  
front clamp with electronic temperature control  
pocket press heating right with bimetal control  
pocket press heating left with bimetal control




Knopfdruckleiste mit elektronischem Temperaturregler  
Brusttaschenheizung rechts mit Bimetallregler  
Brusttaschenheizung links mit Bimetallregler  
front clamp with electronic temperature control  
pocket press heating right with bimetal control  
pocket press heating left with bimetal control


Size	Document Number	Rev
A3	8325, Seite 2	WM
Date:	Wednesday, November 15, 2000	Sheet 2 of 7



Size	Document Number	Rev
A3	8325, Seite 3	WM
Date:	Tuesday, May 23, 2000	Sheet 3 of 7




Size	Document Number	Rev.
A3	8325, Seite 4	WM
Date:	Tuesday, May 23, 2000	Sheet 4 of 7




Size	Document Number	Rev
A3	8325, Seite 5	WMM
Date:	Tuesday, May 23, 2000	Sheet 5 of 7

Datenbus-Verbindung, Steuerspannung  
Data bus connection, control supply



Size	Document Number	Rev
A3	8325, Seite 6	WM
Date:	Tuesday, May 23, 2000	Sheet 6 of 7

### Anordnungsplan




- Alle Bauteile sind zu kennzeichnen, ausgenommen PE-Klemmen  
all components have to be signed except PE-clamps
- PE-Klemme für die Zuleitung ist mit "PE" zu kennzeichnen  
sign PE-clamp for supply line with "PE"
- Alle Schutzleiteranschlüsse sind mit dem Schutzleiterzeichen zu kennzeichnen  
sign all earthed connections with earth-sign
- Codierbrücken an X3.1, X3.2 und X3.3 0.23qmm  
coding bridges to X3.1, X3.2 and X3.3 0.23sqmm
- Alle nicht bezeichneten Hauptleitungen: mind. 0.82mm<sup>2</sup>  
All mains wires not indicated: 0.82mm<sup>2</sup> minimum
- Alle nicht bezeichneten Steuerleitungen: mind. 0.5mm<sup>2</sup>  
All control wires not indicated: 0.5mm<sup>2</sup> minimum

**Farblegende/colour legend:**


gegr	gelbgruen	yellow-green
bl	blau	blue
sw	schwarz	black
rt	rot	red
ws	weiss	white
bn	braun	brown
ge	gelb	yellow
gn	gruen	green

Size	Document Number	Rev
A3	8325, Seite 7	WM
Date:	Tuesday, May 23, 2000	Sheet 7 of 7

## 8 Position of Throttles




- D 1** Moving inwards button clamp
- D 2** Moving outwards button clamp
- D 3** Moving inwards sleeve tensioner right
- D 4** Moving outwards sleeve tensioner right
- D 5** Moving inwards sleeve tensioner left
- D 6** Moving outwards sleeve tensioner left




- D 7** Suction position air box
- D 8** Blowing position air box



### 9 Types of Valves



- Y20** Steam valve
- Y10** Restretching back
- Y 9** Restretching side
- Y 8** Back clamp
- Y 7** Side clamp left
- Y 6** Side clamp right
- Y 5** Unloader
- Y 4** Sleeve clamp right
- Y 3** Sleeve clamp left
- Y 1** Air box




- Option
- Option
- Y14** High pressure front clamp
- Y15** High pressure Y18/Y19
- Y12** Breast pocket
- Y 2** Revers
- Y16** Side tensioner
- Y17** Front clamp
- Y18** Sleeve tensioner right
- Y19** Sleeve tensioner left

**10 Spare Parts**



- 1** 585 201 068 0 Sound absorber 1/8" (2x)
- 2** 929 065 078 0 Quick vent valve (2x)
- 3** 929 065 095 0 Inhibit cylinder AZS5040/100
- 5** 485 105 020 0 End switch AT 11
- 4** 483 153 018 0 Throttle check valve (4x)




- 6** 483 451 021 0 Heating element 8345
- 7** 483 251 142 0 Spray tube




**Installation position of the bearing bottom must not be changed!**

- 8** 483 453 028 0 Compressed air cylinder dia inside 32 - 200




- 9**    **923 063 002 0**    Star grip screw M 6x20
- 10**    **483 303 015 0**    Swivel throttle valve 5/3-M5
- 11**    **483 803 008 0**    Cylinder dia inside 16 - 25




- 12**    **421 282 006 0**    Thermostat cpl.
- 13**    **483 453 032 0**    Cylinder dia inside 16 - 50
- 14**    **483 303 015 0**    Swivel throttle valve 5/3-M5



- 15**    **929 025 002 0**    Ball bushing dia 12 corr.-resist.
- 16**    **483 453 010 0**    Cylinder dia inside 25-160
- 17**    **941 201 086 0**    Quick screwing swivelling  
5/3-1/8"




**18** 929 065 079 0 Compressed air cylinder dia inside 63-80



**19** 483 303 004 0 Compressed air cylinder dia inside 16 - 50

**20** 929 065 073 0 Compressed air cylinder dia inside 25 - 40




**22** 929 065 010 0 Throttle check valve 1/8"-5/3

**21** 483 453 014 0 Compressed air cylinder dia. inside 20 - 80

**23** 583 801 001 0 Compressed air cylinder dia. inside 25 - 50

**24** 929 065 089 0 Mini-pressure regulator 115/115/1/8"



**25**

**929 065 075 0** Compressed air cylinder dia inside 20 - 40

**26**

**923 063 003 0** Clamping lever M 8x25 Nirosta



**27**

**935 081 015 0** Tension spring



**28**

**929 055 045 0** Electro thermostat 0-150°C

**29**

**483 153 013 0** Manometer 0 – 10 bar 1/8"



**30**

**483 153 012 0** Pressure regulator 1/8" 7 bar

**31**

**585 201 065 0** Main switch 380/440 V



**32****483 452 006 0 Steam drier cpl.****33****483 074 001 0 Capsule steam trap 1/2"****34****483 505 016 0 Motor 2,2 kW****35****926 026 002 0 Rubber foot**



**36**


**483 083 000 0 Steam valve**



**37**

**483 153 011 0 Filter control**

**483 151 162 0 Absorbtion glass for filter control**



**38**

**928 015 202 0 Cable box**

**39**


**928 015 200 0 Contact inset / pin**

**40**

**928 015 203 0 Attached box**


**41**

**928 015 201 0 Contact plug / bushing**




- 42**    **483 703 003 0**    **Distributor block**
- 43**    **483 603 000 0**    **Way valve 3/2 – G 1/8“**
- 44**    **483 603 001 0**    **Way valve 5/2 – G 1/8“**

**Pressure regulator for safety-pressure  
adjustment of 1,8 bar**



- 45**    **483 603 000 0**    **Way valve 3/2 – G 1/8“**
- 46**    **483 603 001 0**    **Way valve 5/2 – G 1/8“**
- 47**    **929 065 077 0**    **Way valve 5/3 – G 1/8“**  
*Locking middle position evacuated (4x)*
- 48**    **483 153 018 0**    **Throttle check valve 1/8“**





- |           |   |
|-----------|---|
| <b>49</b> | <b>929 055 006 0</b> Fuse 6,3 A mtr.                |
| <b>50</b> | <b>923 035 000 0</b> Fuse clamp f. mounting f.TS35. |
| <b>51</b> | <b>929 075 063 0</b> Power contactor 415V 4kW       |
| <b>52</b> | <b>929 075 023 0</b> Motor power contactor 1-16     |
| <b>53</b> | <b>483 453 018 0</b> Power supply S-100-24          |
| <b>54</b> | <b>483 453 019 0</b> I/O- card box cpl.             |

Article-No.	Description	Piece
383 251 000 0	Cover / chest	1
383 251 001 0	Felt / chest	1
383 251 002 0	Air bag right	1
383 251 003 0	Air bag left	1
383 251 004 0	Foam cutting / button clamp	1
383 251 005 0	Cover / button clamp	1
383 251 006 0	Needle felt / side tensioner clamp	2
383 251 007 0	Needle felt / button tape tensioner	1
383 251 008 0	Felt / back clamp	1
383 251 009 0	Felt / sleeve tensioner	4
483 251 342 0	Heating / breast pocket	1
483 251 343 0	Heating / button tape	1
928 015 303 0	Double foot switch red/black	1
929 055 048 0	Miniclick temperature fuse heating button clamp (S2, S3)	2
929 055 044 0	Temperature sensor PT 100	1
483 252 620 0	Operation panel cpl.	1


## 11 Information Leaflet

### Replacement of the EPROM

#### Operation panel

1. Disassemble the operation panel
2. Open the operation panel
3. Remove the assembled EPROM carefully with a special tool or with a screw driver
4. Insert the new EPROM (label „XXXX\_XX“) in the base, but please note:
  - the **small mark** at the EPROM must exactly be positioned onto the mark of the base
  - all the PINs must properly be set in the base, they must not be bent or buckled

position of small mark



### Parameterizing of the frequency converter

#### Change the parameterization


1. Actuate the "PRG/Reset"-key (the display shows "F000")
2. Select the parameter to be changed with the arrow-keys ("F???" )
3. Activate the corresponding value by the "Func/Data"-key
4. Change the value by the arrow-keys
5. Confirm the input by the "Func/Data"-key (use the "PRG/Reset"-key to leave the parameterizing mode without changing the parameter)

#### Inquiry of parameterizing

- Do the steps 1-3 and 5

#### Deactivate/activate the parameter protection

- Set the parameter "F000" to 0 (to deactivate) / 1 (to activate). (Use the "Stop"-key and the arrow-keys to change the parameter)



### Parameters of the frequency converter

Parameter	Adjustment of VEIT	Meaning of the parameters	Remarks
F00	1	Blocking of input	Changes only by using the "Stop"- and "arrow"-keys.
F01	1	analog nominal value	
F02	1	Operating via terminal strip	
F03	50	max. frequency	
F04	50	corner frequency	
F05	230	rated voltage (max. output voltage)	
F06	0.80	acceleration time	
F07	2.00	deceleration time	
F08	0	automatic torque boost	
F09	85	FMA voltage adjustment	
F10	4	motor poles: 4	
F11	0.02	speed display coefficient	
F12	15	motor operating sound adjustment (carrier frequency) (kHz)	
F13	5	No. of retries	
F14	2	active restart after momentary power failure (operation selection)	
F15	1	electronic thermal overload relay 1 (operation selection) active (standard motor)	
F16	9.20	electronic thermal overload relay 1 (operating level) (A)	
F17	1	active DC brake (operation selection)	
F18	20	DC brake (starting frequency)	

<b>F19</b>	<b>50</b>	DC brake (braking level)	
<b>F20</b>	<b>0.50</b>	DC brake (braking time)	
<b>F21</b>	<b>0.00</b>	multistep frequency setting 1 /Hz)	
<b>F22</b>	<b>0.00</b>	multistep frequency setting 2 (Hz)	
<b>F23</b>	<b>0.00</b>	multistep frequency setting 3 (Hz)	
<b>F24</b>	<b>0.00</b>	multistep frequency setting 4 (Hz)	
<b>F25</b>	<b>0.00</b>	multistep frequency setting 5 (Hz)	
<b>F26</b>	<b>0.00</b>	multistep frequency setting 6 (Hz)	
<b>F27</b>	<b>0.00</b>	multistep frequency setting 7 (Hz)	
<b>F28</b>	<b>0</b>	inactive (linear acceleration/deceleration) of S-curve acceleration/deceleration (operation selection)	
<b>F29</b>	<b>-</b>	protection history (last 4 protection operations are displayed in order)	
<b>F30</b>	<b>10</b>	starting frequency (Hz)	
<b>F31</b>	<b>120</b>	torque limit active (during acceleration/deceleration)	
<b>F32</b>	<b>100</b>	torque limit active (at constant speed)	
<b>F33</b>	<b>0</b>	braking torque selection low (no DB option)	
<b>F34</b>	<b>6</b>	bias frequency	
<b>F35</b>	<b>100.0</b>	gain for frequency setting signal	
<b>F36</b>	<b>50</b>	frequency limiter (high)	
<b>F37</b>	<b>10</b>	frequency limiter (low)	
<b>F38</b>	<b>5</b>	motor characteristics	
<b>F39</b>	<b>0</b>	manual setting	
<b>F40</b>	<b>0</b>	analog signal output from FMA terminal	
<b>F41</b>	<b>0</b>	output frequency	
<b>F42</b>	<b>24</b>	FMP terminal (Pulse rate multiplier)	
<b>F43</b>	<b>0</b>	X4 terminal function: RT1	
<b>F44</b>	<b>0.00</b>	multistep frequency setting 8	
<b>F45</b>	<b>0.00</b>	multistep frequency setting 9	
<b>F46</b>	<b>0.00</b>	multistep frequency setting 10	
<b>F47</b>	<b>0.00</b>	multistep frequency setting 11	
<b>F48</b>	<b>0.00</b>	multistep frequency setting 12	
<b>F49</b>	<b>0.00</b>	multistep frequency setting 13	
<b>F50</b>	<b>0.00</b>	multistep frequency setting 14	
<b>F51</b>	<b>0.00</b>	multistep frequency setting 15	
<b>F52</b>	<b>0.06</b>	frequency setting signal filter	
<b>F53</b>	<b>0.00</b>	timer	
<b>F54</b>	<b>1</b>	Y1E terminal (function selection): frequency level detection (FDT)	
<b>F55</b>	<b>50.00</b>	frequency level detection (FDT operation level)	
<b>F56</b>	<b>10</b>	hysteresis width (FDT or FAR)	
<b>F57</b>	<b>0</b>	THR function	
<b>F58</b>	<b>3</b>	jump frequency (hysteresis width)	
<b>F59</b>	<b>0</b>	jump frequency 1	
<b>F60</b>	<b>0</b>	jump frequency 2	
<b>F61</b>	<b>0</b>	jump frequency 3	
<b>F62</b>	<b>50</b>	base frequency 2	

<b>F63</b>	<b>10.0</b>	acceleration time 2	
<b>F64</b>	<b>10.0</b>	deceleration time 2	
<b>F65</b>	<b>13</b>	torque boost 2	
<b>F66</b>	<b>1</b>	electronic thermal overload relay 2 (operation selection) (active Standard motor)	
<b>F67</b>	<b>10.5</b>	electronic thermal overload relay 2 ( operating level)	
<b>F68</b>	<b>0.0</b>	slip compensation inactive	
<b>F69</b>	<b>0</b>	torque vector control inactive	
<b>F70</b>	<b>1</b>	motor capacity standard	
<b>F71</b>	<b>9.20</b>	motor 1/rated current	
<b>F72</b>	<b>4.85</b>	motor 1/mo-load current	
<b>F73</b>	<b>9.20</b>	motor 2/rated current	
<b>F74</b>	<b>1</b>	automatic tuning inactive	
<b>F75</b>	<b>(18.56)</b>	motor 1 (%R1 setting)	
<b>F76</b>	<b>(33.14)</b>	motor 1(%X setting)	
<b>F77</b>	<b>390</b>	torque limiter response (at constant speed)	
<b>F78</b>	<b>394</b>	torque limiter response (during acceleration/deceleration)	
<b>F79</b>	<b>0</b>	option selection (no options)	



## 12 EC Declaration of Conformity

**EG-Konformitätserklärung/ EC declaration of conformity / Déclaration "CE" de conformité  
EF-overensstemmelseserklæring/ EG-verklaring van overeenstemming  
Declaración CE de conformidad / Dichiarazione CE di conformità / Declaração CE de  
conformidade**

**Hemdenfinisher / Shirt Finisher VEIT 8325** Seriennummer: \_\_\_\_\_

Hiermit erklären wir, daß die Bauart des genannten Geräts in der gelieferten Ausführung folgenden einschlägigen Richtlinien entspricht

Herewith we declare that the supplied model complies with the following provisions applying to it

Par la présente, nous déclarons, que le modèle correspond aux dispositions pertinentes suivantes

Hermed erklæres, at produkttypen er i overensstemmelse med følgende bestemmelser

Hiermede verklaren wij, dat de in de handel gebrachte machine voldoet aan de eisen van de in het vervolg genoemde bepalingen

Por la presente, declaramos que el modelo suministrado satisface las disposiciones pertinentes siguientes Si dichiara che il modello fornito della è conforme alle seguenti disposizioni pertinenti

Com a presente, declaramos que o modelo fornecido da está em conformidade com as disposições pertinentes, a saber

**EG-Richtlinie Maschinen 89/392, Elektromagnetische Verträglichkeit 89/336**

Angewandte harmonisierte Normen, insbesondere

Applied harmonized standards, in particular

Normes harmonisées utilisées, notamment:

Harmoniserede standarder, der blev anvendt, i særdeleshed

Gebruikte geharmoniseerde normen, in het bijzondere


Normas armonizadas utilizadas, particularmente

Norme armonizzate applicate in particolare

Normas harmonizadas utilizadas, em particular

**EN 292-1, EN 292-2, EN 50082-2, EN 55011, EN 50081, EN 60204-1**

Landsberg, 20.09.2000



D. Töwe

Geschäftsführer / Vice President & Managing Director

**VEIT GmbH & Co.**

**Justus-von-Liebig-Straße 15**

**D-86899 Landsberg / Lech**





**To:**  
**VEIT - Service -**  
**Justus-von-Liebig Str. 15**  
**D- 86899 Landsberg / Lech**  
**Germany**  
**Fax: +49 (8191) 479 - 230**

# Registration

**VEIT always tries to improve its products. To do this, we need to be supported by you. We will register your answers which will enable us to inform you directly about any technical improvements.**

**1.) How did you become aware of the product?**

- VEIT employee / dealer
- Internet
- Exhibition \_\_\_\_\_
- Other \_\_\_\_\_
- Magazine \_\_\_\_\_

**2.) What is your opinion about the following points:**

	good			bad	
Support at the sales decision	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Installation	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Instruction	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Manual	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Operation of the unit	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Result of the operation	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Quality of the machine	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

**3.) Suggestions for improvement:**

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

**Address:**

Name: \_\_\_\_\_

Street: \_\_\_\_\_

Place/Country: \_\_\_\_\_

Phone: \_\_\_\_\_

Fax: \_\_\_\_\_

Thank for your help!

